## 15 Color Programs (Only for RGB lamps)

Fixed Blue

Fixed Red

3 Fixed Green

4 Fixed Red/Blue

Fixed Blue/Green

6 Fixed Red/Green

Fixed White

8 Cycle Red-Red/Green-Green

9 Cycle Green-Green/Blue-Blue

10 Cycle Red-Red/Blue-Blue

Cycle Red-Green-Blue, Speed from fast to low.

12 Same as program 11, the speed is slower.

Cycel Green-Red/Blue-Blue-Red-White-Blue/Green-Red/Green

14 Cycle gradual change of all colors.

Cycle gradual change of Red-Green-Blue.

## **Operation**

## **Changing colors:**

Turn the lamps OFF and quickly back ON (0-3 seconds).

### **Synchronizing multiple lamps:**

- 1. All lamps need to be connected to the same transformer.
- 2. Turn the lamps OFF and back ON within 5-30 seconds.
- 3. All the lamps back to first program (blue).

## Memorizing the last color:

Select the desired color, turn OFF the lamps more than 34 seconds, the chosen color has now been memorized.

#### **ACQUA SOURCE S.A.**

Manufacturer of swimming pool and fountain products

15 Souri str., 121 31 Peristeri, Athens, Greece Tel. & Fax: +30 210 5721058, +30 210 5771863, +30 210 5774345 E-mail: info@acquasource.gr

www.acquasource.gr



# **WPLD-6R**

## **Wall Mounted Lamp Installation Instruction**












#### PLEASE READ THE FOLLOWING CAREFULLY AND **KEEP THIS USER MANUAL SAVE FOR FUTURE REFERENCE**

ITEM NO.	Voltage	Power	Color	Lumens	LED Type	LED Qty	Control
WPLD-6R162-PBWW	AC12V	10W	Warm White 3000K	1000lm	SMD2835	162pcs	/
WPLD-6R162-PBCW	AC12V	10W	Cool White 6400K	1100lm	SMD2835	162pcs	/
WPLD-6R162-PBB	AC12V	10W	Blue	450lm	SMD2835	162pcs	/
WPLD-6R162-PBM	AC12V	10W	RGB	550lm	SMD2835	162pcs	Remote

## **DIMENSION**



## **INSTALLATION**

- 1. Input voltage is AC12V. The lamps must be connected with transformer.
- 2. The junction box is located at least 1200mm from the edge of the pool.






Figure 1

3. The mounting bracket must be properly installed so that the top edge of the light's lens is at least 450mm below the water level in the pool. see Figure 1.

4. Make sure the surface of pool wall is flat. Fix the bracket with 4pcs screws.





5. If the cable connection is done underwater, the connection part must be **waterproof protected** (use waterproof cable gland or fill with epoxy glue). Otherwise, the water will come in the lamp through the wires.



- 6. Connect all wires to the corresponding circuit wires in the junction box and feed epoxy.
- 7. Before operating the light for more than 10 seconds fill pool until the light is completely submerged in water.
- 8. It is easy to replace the lamp.

